Project Documentation

Commodore VIC-20 Diagnostic Keyboard PCB

Project number: 156

Revision: 0

Date: 15.09.2020

Commodore VIC-20 Diagnostic Keyboard PCB Rev. 0

Module Description

The Keyboard PBC provides the feedbacks for the keyboard connector, which are required for the Commodore VIC-20 Diagnostic software. The LED works as an alternative Power LED.




Figure 1: Dimensions of the Keyboard PCB

Connectors

Keyboard Connector (J1)

Pin	Signal
1	GND
2	No Pin
3	RESTORE
4	+5V
5	COL7
6	COL6
7	COL5
8	COL4
9	COL3
10	COL2
11	COL1
12	COL0
13	ROW7
14	ROW6
15	ROW5
16	ROW4

19.10.2020 18:36

Doc.-No.: 156-6-01-00

Pin	Signal
17	ROW3
18	ROW2
19	ROW1
20	ROW0

RESTORE Cable (J2)

This is a solder pad for the RESTORE Cable (Doc.-No. 159-3-04-**) from the cable set. The cable is soldered to the pad and a knot serves as a strain relief.



Figure 2: Keyboard PCB with the RESTORE cable soldered to J2 and tied to the PCB


This cable is connected to a single pin of the User Port PCB.

Interconnects


Signal		Signal
RESTORE	\rightarrow	User Port Pin 9 (ATN)
COL7	\leftrightarrow	ROW7
COL6	\leftrightarrow	ROW6
COL5	\leftrightarrow	ROW5
COL4	\leftrightarrow	ROW4
COL3	\leftrightarrow	ROW3
COL2	\leftrightarrow	ROW2
COL1	\leftrightarrow	ROW1
COL0	\leftrightarrow	ROW0

19.10.2020 18:36

Doc.-No.: 156-6-01-00




Sven Petersen	Doc.	-No.: 1!	56-2-01-00
2020	Cu:	$35\mu m$	Cu-Layers: 2
VIC-20_Diag_Keybo	ard		
17.09.2020 16:20			Rev.: 0
placement component	side		




Sven Petersen	Doc.	-No.: 1	56-2-01-00
2020	Cu:	$35\mu m$	Cu-Layers: 2
VIC-20_Diag_Keybo	ard		
17.09.2020 16:20			Rev.: 0
		r side	placement solde




Sven Petersen	Doc	-No.: 1!	56-2-01-00
2020	Cu:	35μ m	Cu-Layers: 2
VIC-20_Diag_Keybo	ard		
17.09.2020 16:20			Rev.: 0
top			




Sven Petersen	Doc.	-No.: 1!	56-2-01-00
2020	Cu:	$35\mu m$	Cu-Layers: 2
VIC-20_Diag_Keybo	ard		
17.09.2020 16:20			Rev.: 0
bottom			




Sven Petersen	Doc.	-No.: 1!	56-2-01-00
2020	Cu:	$35\mu m$	Cu-Layers: 2
VIC-20_Diag_Keybo	ard		
17.09.2020 16:20			Rev.: 0
stopmask component	side		



Sven Petersen	Doc.	-No.: 1	56-2-	01-00
2020	Cu:	$35\mu m$	Cu-La	уегѕ: 2
VIC-20_Diag_Keybo	ard			
17.09.2020 16:20			Rev.:	0
stopmask solder side	!			



Sven Petersen	Doc.	-No.: 1	56-2-	01-0	0
2020	Cu:	$35\mu m$	Cu-La	уегѕ:	2
VIC-20_Diag_Keybo	ard				
nicht gespeichert!			Rev.:	0	
placement component	side	mea	sures		



VIC-20 Diagnostic Keyboard PCB Rev. 0 Bill of Material Rev. 0.0

Pos.	Qty Value	Footprint	RefNo.	Comment
_	1 156-2-01-00	2 Layer	PCB Rev. 0	2 layer, Cu 35µ, HASL, 53.0mm × 14.0mm, 1.6mm FR4
2	1 3mm/green	3MM	LD1	LED
က	1 Restore cable	1X01	J2	Cable (DocNo. 159-3-04-**) from cable set soldered to
				J2, see module description
4	1 330R	R-10	R1	1/4 Watt, 5%
5	1 BL1-85AXX-20U	BL1-85AXX-20U	U JI	20 socket connector, 90°, 2.54mm pitch. E.g. MPE Garry, Reichelt BI 1x20W8 2.54
				.) (1)

19.10.2020 14:53 Doc.No.: 156-5-01-00.0